

6.7 USB Update

This function makes users update the system more easily through USB memory stick directly.



1. Insert USB memory stick into USB port on the front panel of DVR. It may take 3~4 seconds to detect it.

You can check in the “Information” menu if DVR detects it or not.

2. Select “USB Update” menu and press Enter button.

Note USB stick memory format in your PC

You have to format it by only **“FAT 32”** as file system.



3. New software is displayed on the monitor.

Note DVR can read out maximum 20 softwares from USB memory stick.

4. Select the one that you want to download and then press Enter button.



“USB File Error” message happens in case of ;

1. USB memory stick has no software.
2. USB memory stick is not connected into DVR properly.

Triplex Real Time Stand Alone DVR



5. Select “**YES**” and then press Enter button.

If you select “**NO**”, then you will move to the previous menu.



6. DVR starts downloading, showing “**System Update**”.

CAUTION !

- If you remove USB stick during proceeding the download, DVR may be shut down (or in crash).



7. DVR shows “**Update Success**” after completing system update, and then it reboots automatically.